



Charger Safety Instructions

Your MeloYelo charger is a premium quality charger, and you should not experience any issues with it.

Your AC (three-pin) charger's input range is 100V – 240V.

Before charging:

1. Connect the charger to your battery first
2. Then connect it to your wall outlet
3. And then switch it on

After charging:

1. Switch the outlet off and unplug your charger from the wall first
2. Then unplug it from your battery

Be aware:

- The charger is designed for indoor use only, do not expose it to rain or snow
- Do not wash your charger with water. Use a moist cloth
- Disconnect equipment from the power supply before cleaning
- Do not cover your battery or charger while charging
- Do not charge your battery around flammable materials
- Do not attempt to open the charger
- Leaving your battery in the bike while charging reduces the possibility of damage by dropping it.
- When disposing of your charger, try and dispose of it at an e-waste recycling facility.

Review Fire and Safety NZ's safety tips for lithium-ion battery tips [here](#).